



FIXING INSTRUCTIONS FOR 1000 X 400 X 50MM DOUBLE BULLNOSE WALL CAPPING

Please note we recommend that an Engineer check to confirm the suitability of the suggested fixing instructions.

1. The steel supports should have six pins 10mm diameter and 30mm high welded to the support. Two pins 100mm in from either end and two centred.
2. FC sheet 1000 x 300 x 10mm placed on steel supports with holes drilled for pins. Use suitable adhesive to glue in place.
3. Make a template to follow pins and drill 20mm holes in the back of the double bullnose wall capping.
4. Fill holes and butter pins with an epoxy glue.
5. Then bed stone on a rubber based tile/stone adhesive.
6. Grout joints 6-8mm with matching coloured grout supplied by the manufacturer.
7. Clean off any excess adhesive immediately from the face of the product to prevent staining. (Please refer Chelmstone's Installation and Trade Information)
8. Use an expansion material ie Sika-Flex between the Chelmstone and any other surfaces.