



PIER AND WALL CAPPING INSTALLATION PROCEDURE

1. Pier caps and wall caps can be glued down using either a mortar mix or cement based tile adhesive (as per the manufacturers instructions).
2. Mix 2 litres latex bonding agent (Kemcrete, weldcrete), 4kg neat cement, and 2 Lt water, then mix thoroughly. Use this mix to brush on the underside of the capping.
3. Bed allowing 8-10 mm joints using a string line to keep line's straight.
4. If the capping butts into any other surface use an expansion joint material, such as Sikaflex.
5. Allow for expansion joints every 4 metres as per industry standards.
6. Make sure any mortar or other material is sponged off the product immediately to prevent staining.
7. Joints can be grouted using Chelmstone's colour matching grout, or a mix of fine white sand and white cement.
8. It is our recommendation that an experienced installer is called upon to install all pier and wall capping.